


ZERO-TX2^{Mini}




M A N U A L

Overview



Pairing




Open the lid and "Power on" and connect automatically

Turn on Bluetooth on your phone and tap on "ZERO-TX2 Mini" when it appears in the device list.

Earphone installation



Operation



Play /Pause



Skip track



Adjust Volume



Answer/Hang up



Reject Call



Voice Assistant

Reset

1. Delete the earbuds from device and take out the earbuds from the box.
2. Hold both the R and L earbuds simultaneously for 5 seconds. You will hear a melody indicating a successful reset.
3. Insert the earphones into the charging case and re-initiate the pairing process.

Troubleshooting

① Can be connected but there is no sound:

Click the right earbuds to increase the volume.

② One of earbuds cannot be charge:

Clean the charging contact of the earbuds and the charging case.

③ One of the earbuds cannot be connected:

Reset the earbuds.

If you are unable to resolve the issue, please don't hesitate to contact our support team at: support@soundbysweden.com



Please clean the charging contacts of the earbuds and charging case frequently to avoid charging failures.

Technical Data

Bluetooth version: Bluetooth V5.4

Maximum transmission range: $\leq 10\text{M}$

Audio Code: SBC/AAC

Working temperature range: $-10^{\circ}\text{C} \sim +45^{\circ}\text{C}$

Operating frequency: 20HZ-20KHZ

Bluetooth profiles supported: HFP, HSP, A2DP, AVRCP

Earbuds battery capacity: 3.7V 30mAh

Box battery capacity: 3.7V 400mAh

Speaker drivers: ϕ 6mm 32 Ω

Mic: $-40\text{db} \pm 3\text{db}$

Music playing time: 5-6h depending on volume

Charge time: Approx. 1.5h

Buttons: Touch Control

What is in Package Box



Earbuds



USB-C
charging cable



Manual



2 sets
eartips